


## LORO-X Abflusskurve



<b>Wasserhöhe</b>	<b>[mm]</b>	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
<b>Abfluss Q</b>	<b>[l/s]</b>	-	0,70	1,20	2,50	3,50	4,50	5,10	5,80	Sammelkasten läuft über / Vollfüllung							

